

Instruction Manual for A8000 Series

A 8 D - 0 for Temperature measurement
- resistance temperature detector



CAUTION


- (1) Applying a voltage or current exceeding its maximum permissible value may cause the unit to be damaged.
- (2) Always use the unit within the specified voltage range: otherwise, it may cause a fire, electric shock or personal/equipment damage.
- (3) For the purpose of functional improvement, the information written herein may be changed without prior notice.
- (4) Information contained herein is considered accurate to the best of our knowledge. If you have any question or comment on the information, please contact us or our distributor.
- (5) Read this manual carefully and thoroughly before starting to operate the unit, and keep the manual available for future reference.

1. Before Using the Unit

Thank you for purchasing our A8000 Series Digital Panelmeter. Please make sure that the operator who uses the panelmeter keeps the manual on hand. Also, the meter should be checked upon receipt for damage that might have occurred while in transit. Should the product be damaged or any accessory be missing, notify your sales representative or our sales office directly.

1.1 Model and Suffix Code Configuration

The model and suffix code of the A8000 series are as shown below. Check that the product received matches the one you selected when ordering.



[CAUTION]: This machine become it if there are neither BCD output nor External control when selecting it only for the display.

1.2 Checking the Accessories


The A8000 series accessories include one copy of this Operation Manual and one unit label.

*when BCD is selected by the option,BCD connector(Card edge type 26P)is attached.

2. Mounting Method


2.1 Panel Cutout Size

Panel cutout for mounting the A8000 series digital panelmeter is as shown below:



* Recommended panel thickness: 1 to 8 mm


2.2 External Dimensions



* In case of No switch display option, there is not print on the front panel.

2.3 How to Mount the Unit on the Panel




With the mounting bands detached from the main unit, insert the main unit into the opening in a panel from the front of the panel, and then attach the mounting bands to the main unit from the rear of the panel for fixing.



CAUTION

- (1) Do not install the unit where it is exposed to dust, particles, chemicals harmful to electric components, corrosive gases, etc.
- (2) When this unit is installed inside other equipment, pay attention to the heat radiation and keep the heat inside the equipment 50°C or below.
- (3) Exercise care so that the product is not subject to vibrations or shocks.

3. Terminals and Connections




Lower terminals

- ①: Resistance element conductor connection terminal A
- ②: Resistance element conductor connection terminal B
- ③: Connection terminal of a conductor resistance rejection wire C
- ④, ⑤: NC terminals
 - Do not connect anything to the NC terminals.
- ⑥: Power terminal (DC POWER 0 V)
- ⑦: Power terminal (DC POWER +V)
 - The A8000 series panelmeter has no power switch; connecting it to a power source causes it to be operable immediately.

Upper terminals (only for units with BCD outputs)

This machine become it if there are neither BCD output nor External control when selecting it only for the display.



- Caution**
- (1) The BCD output logic can be switched using the BCD logic parameter (BCD.L) of the condition data, which is positive when BCD.L is set to P.LOG and negative when BCD.L is set to N.LOG for an output type of Open collector. This logic is reversed if the output type is "TTL."
 - (2) The lock function is not provided in the BCD connector, and use it, please with the load doesn't hang to the connector.

1 to 17: Outputs of bits 1, 2, 4, and 8 of each digit

18: BCD overrange output

19: BCD polarity output

20: BCD printout command output

21: Digital Zero

- Shorting this terminal and D.COM terminal or bringing their potential to the "0" level allows the meter to perform measurements with the previously displayed value as "zero." This feature displays the width of variations from that point onward.

22: Peak Hold

- Shorting this terminal and D.COM terminal or bringing their potential to the "0" level allows the meter to display and hold the maximum value (Peak Hold), minimum value (Valley Hold), or the difference between the maximum and minimum values (Peak – Valley Hold). These functions can be switched using condition data.

23: BCD Enable

- Shorting this terminal and D.COM terminal or bringing their potential to the "0" level causes BCD output to be high impedance or the transistor to be turned OFF.

24: Hold

- Shorting this terminal and D.COM terminal or bringing their potential to the "0" level causes the panelmeter to maintain its indication.


25, 26: D.COM

- Common terminals for BCD outputs and control terminals
- "0" level: 0 to 1.5 V, "1" level: 3.5 to 5 V, and input current: -0.5 mA

4. Parameter Settings

4.1 Components and Functions

- ① Main display unit: Displays a measured value or a menu or parameter information during



- parameters setup.
- ② Function monitoring indicator: Lights up when the control function is being used or blinks when a variety of settings is made.
- ③ Enter switch: Shifts the panelmeter from measurement status to parameter setting status (Enter + Mode).
- ④ Mode switch: Shifts to the item you wish to change during parameter setting. Shifts to a shift data setting status (Mode + Shift)
- ⑤ Shift switch: Digital zero ON/OFF control on the front panel (Mode + Increment) Moves to the digit where you wish to carry out setup during parameter setting.
- ⑥ Increment switch: Shifts to a shift data setting status (Mode + Shift) Allows you to choose a numeric value during parameter setting (Increment) or select information. Digital zero ON/OFF control on the front panel (Mode + Increment)

* If condition data "b.up" is Off, disconnecting the power supply causes a digital zero value to be cleared. In case of No switch display option, there is not print on the front panel but the switches are implemented.

4.2 Numeric and Character Indications

0 1 2 3 4 5 6 7 8 9 - /
 0 1 2 3 4 5 6 7 8 9 - /
 A B C D E F G H I J K L M N O P Q R S T U V W X Y Z
 a b c d e f g h i j k l m n o p q r s t u v w x y z

4.3 Parameter Types and Protect Levels


The 43DV2 series parameters are classified into the following groups depending on the main objective. Use of the protect setting in the condition data allows a limitation to be imposed on the settable parameters.

Condition data: A group of parameters that set up basic actions such as the sampling rate and operation type for each control.

Scaling data: A group of parameters relating to measurements such as scaling.

Linearize data: A group of parameters relating to the function of correcting the linearity of an input value and display value.

4.4 Shift to the Parameter Setting Mode



When the Enter key is pressed, the panelmeter stores data and returns to measurement operation.

4.5 Protect Levels

Protect level 0 (PL0):

Allows all parameters to be displayed (set).

Protect level 1 (PL1):

Allows condition and scaling data to be displayed (set).

Note: Condition data display (setting) is available only for protection, range, and the number of averaging (sampling) times.

Protect level 2 or 3 (PL2, 3): Allows display (setting) of only condition data protect levels.

4.6 A setting method of each parameter

4.6.1 Setting Condition Data

Condition data is a group of parameters for setting up basic actions such as a protect level, measurement range, and each control's operation type.

Measurement operation

12345

- (1) Press the Enter and Mode keys during measurement operation to enter the condition data setting mode.

cond

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL

PL



PL

PL

PL

PL


- (2) Press the Mode key to move to protect level setting.
- (3) Press the Mode key to display the current protect level.
- (4) Set up the desired protect level using the Increment key. (This setting example sets the protect level to PL1.)
 PL0: Displays all the parameters.
 PL1: Displays only the condition and scaling data.
 PL2/3: Displays only the condition data.
 * If you do not set a protect level, press the Mode key to move to the next item.
- (5) Press the Mode key to move to peak-hold-type setting.
- (6) Set up the peak hold type using the Increment key.
 PH: Holds the maximum display value.
 PV: Holds the minimum display value.
 PVH: Holds (holds) the difference between the maximum and minimum values.
 * If you do not set the peak hold type, press the Mode key to move to the next item.
- (7) Press the Mode key to move to range setting.
- (8) Set the range using the Increment key.
 PA: Pt1000 (0.1 Resolution)
 PB: Pt1000 (1 Resolution)
 JPA: JPt1000 (0.1 Resolution)
 JPB: JPt1000 (1 Resolution)
 * If you do not set the range, press the Mode key to move to the next item.
- (9) Press the Mode key to move to averaging count setting.
- (10) Set the number of averaging times using the Increment key.
 1: Single averaging (approx. 12.5 times/sec)
 2: Twice averaging (approx. 6.25 times/sec)
 4: Four-time averaging (approx. 3.125 times/sec)
 8: Eight-time averaging (approx. 1.5625 times/sec)
 10: Ten-time averaging (approx. 1.25 times/sec)
 20: Twenty-time averaging (approx. 0.625 times/sec)
 40: Forty-time averaging (approx. 0.3125 times/sec)
 80: Eighty-time averaging (approx. 0.15625 times/sec)
 100: Hundred-time averaging (approx. 0.125 times/sec)
 200: Two hundred-time averaging (approx. 0.0625 times/sec)
 * If you do not set the number of averaging times, press the Mode key to move to the next item.



4.6.2 Setting Scaling Data

Scaling data is a group of parameters relating to measurements such as scaling or decimal points.

Measurement operation




Example of setting scaling data:

Example of setting 1

A digital limit type chooses CUT by condition data.

DLHI : 1000
DLLO : -50



* Digital Limit Function

The digital limit function is a function for controlling display indication by concurrent use of digital limiter-type setting in the condition data and a digital limit set value in the scaling data.

If CUT is selected for the digital limiter type in the condition data, the display value is held at the limit value set in the scaling data as shown in example of setting 1 above. Moreover, selection of OVER for the digital limiter type causes "o.L." to appear if an input is made that results in exceeding the limit value set in the scaling data.

4.6.3 Setting Linearize Data

Linearize data is a group of parameters relating to the function of correcting the linearity between input and display values. The linearize function corrects the linear relationship between input and display values at any point to change the inclination of the linearity. Linearize data is set using an input value (display value before correction) and output value (display value after correction) at any point.

To use the linearize function, carry out this linearize data setup first and then set the linearize function for activation in the condition data. The linearize function works only after that.

Measurement operation

12345

- (1) Press the Enter and Mode keys during measurement operation to enter the condition data setting mode.

cond

- (2) Press the Shift key twice to move to the linearize data setting mode.

LnE

- (3) Press the Mode key to display linearize point count setting.

n-0.0

- (4) Set the number of linearize points using the Shift and Increment keys.
(This setting example sets the number of linearize points to "10.")

10

- (5) Press the Mode key to display a linearize point.
(6) Press the Mode key to display input value setting with respect to the linearize point selected.
"RE" LED also blinks during setting of an input value.
* The input value is a display value for an input before executing linearization.

0.1

- (7) Press the Mode key to display output value setting with respect to the linearize point.
"DZ" LED also blinks during setting of an output value.
* The output value is a display value for the input made after execution of linearization.

0.2

- (8) Press the Enter key to return to measurement operations.
* After completion of setting, carry out linearize function setup in the condition data to activate this function for use.

23456

23456

23456

23456

23456

23456

23456

23456

23456

23456

23456

23456

23456

5. Other Functions

5.1 Display Shift Function

The display shift function is a function for arbitrarily shifting only the indication without changing the inclination of an input signal.

Measurement operation

12345

- (1) Press the Enter and Mode keys during measurement operation to enter the display shift setting mode.

SHF

- (2) The panelmeter enters the shift numeric setting mode.

0

- (3) Set the number of digits by which you wish to shift the display indication, using the Shift and Increment keys.
(This setting example sets a full-scale display value to "-345.")

-0345

- (4) Check the computation results using the Mode key.
In this case, the decimal points of the 10^2 digits and 10^3 digits blink.
(5) Press the Enter key to return to measurement operation.
* To clear the display shift function, set "0."

12000

12000

12000

12000

12000

5.2 Monitoring Mode

The A8000 series can display the maximum value, minimum value, the difference between them (maximum value – minimum value), and input values in the main display. Pressing the Increment key with the Enter key held down causes the panelmeter to enter the display status in each mode. To switch to each mode, press the Shift key for approximately one second. This switches the display value in the order of the maximum value, minimum value, and the difference (maximum value – minimum value), and the input value. Moreover, pressing the Increment key for approximately one second allows you to clear the display value. Press the Enter key to return to the normal indication. (The next time you enter the monitoring mode, the mode you were in when you exited on the previous occasion is activated.)

Maximum value: The maximum value is displayed, blinking the decimal point of the 10^4 digit.

Minimum value: The minimum value is displayed, blinking the decimal point of the 10^0 digit.


Maximum value – minimum value: The difference between the maximum and minimum values is displayed, blinking the decimal points of the 10^0 and 10^4 digits. If a display value exceeds the displayable range, the indication of the 10^3 digit becomes \square , lighting up its decimal point.

Input value: The input value is displayed, blinking the decimal points of the 10^0 and 10^1 digits.

5.3 Tracking Zero

The tracking zero is a function for automatically digitally correcting the movement of the zero point inside. This function starts to work at the instant the digital zero function is enabled. Correction is made according to the values set for the tracking zero time setting and tracking zero width setting in the condition data.

Example of setting: Tracking zero time setting 5 (correction made every averaging (sampling))
Tracking zero width setting 3 (correction width of 3 digits)



- (1): Indication of the digital zero function is zero.
(2)(3): Because the indication at the 5th sampling is 3 digits or below, correction is made to display zero.
(4): No correction is made because the display value is out of the correction range.
(5): Correction is made to display zero because the display value is three digits or less.

* The setting conditions are $N - 1 < N - 2 \dots N - 15 < N - 16$, and if these conditions are not met, "Err" appears. If this happens, carry out the setting again. The number of linearize points is up to 16, but a value "17 to 19" is also displayed during setup. Note that if you set a value from 17 to 19, it is forced to set it to "16."

6. External Control Function

For those equipped with BCD outputs, there are the hold, digital zero (terminal control), and peak hold functions that can be external controlled.

The external control terminals are DC isolated from the power and input terminals.

6.1 Hold Function

The hold function is a function for stopping indication at an arbitrary timing. It is activated by shorting the HOLD and D.COM terminals or bringing their potential to the "0" level.

6.2 Digital Zero Function

The digital zero function is a function for resetting indication to zero at an arbitrary timing and then displaying a range of variations from that point onward. ON/OFF of the digital zero function can be controlled either by the terminal control or by using keys on the front panel.

For terminal control, this function is activated by shorting the DZ and D.COM terminals or bringing the potentials of them to the "0" level.

For control using front-panel keys, it can be activated by pressing the Increment key with the Mode key held down. Taking the same step again causes this function to be deactivated.

For operation using the control terminals or the front panel keys, terminal control has precedence over front-panel key operation.

6.3 Peak Hold Function

The peak hold function is a function for holding the maximum value (Peak Hold), the minimum value (Valley Hold), and the difference between them (Peak Valley Hold). Switching between these holding functions is achieved using condition data. The peak hold function is activated by shorting the P/H and D.COM terminals or bringing their potential to the "0" level.

6.4 Control Terminal Levels

The levels of each control terminal are as shown below:

"0" level: 0 to 1.5 V

"1" level: 3.5 to 5 V

Input current: -0.5 mA

7. Specifications

■ Input Specifications

● Temperature measurements - resistance temperature detector

Range	Sensor	Measuring range	Resolution	Accuracy
PA	Pt100	-100.0 ~ +199.9	0.1	± (0.15% of FS)
JPA	JPt100			
PB	Pt100	-100 ~ +600	1	± (0.3% of FS)
JPB	JPt100			

Current flowing through resistance : 1mA (TYP)

External resistance : Less than 10 /1lead

Burnout warning : - - -

Linearizer : Digital linearizer

■ Common Specifications

Input circuit:	Single-ended type
Operation system:	$\Delta\Sigma$ conversion method
Display:	7-segment LED, red, character height of approx. 10 mm
Sampling rate:	12.5 times/sec maximum
Display range:	-19999 to 19999
Overrange warning:	"o.L" or "-o.L" indication with respect to an input signal exceeding the display range
Zero indication:	Leading zero suppression
Operating temperature and humidity ranges:	0 to 50°C, 35 to 85% R.H (no condensation)
Storage temperature and humidity ranges:	-10 to 70°C, 60% R.H or less (no condensation)
External dimensions:	48 mm (W) x 24 mm (H) x 89.1 mm (D) (when equipped with BCD outputs)
Weight:	Approx. 70g
Dielectric strength:	500 V DC for 1 minute between the power terminal and each of the input, BCD output, and external control terminals 500 V DC for one minute between the input terminal and each of the BCD output and external control terminals 1500 V AC for one minute between the casing and each terminal
Insulation resistance:	100 M Ω or more at 500 V DC between the above-noted terminals

■ Power Specifications

Supply voltage range:	4.75 to 13.2 V DC 10.8 to 26.4 V DC
Power consumption:	approx. 2 W

■ Option Specifications

● BCD Outputs

◎ TTL output

Measured data:	Tri-state parallel BCD
Polarity signal:	1 level for negative indication
Overrange signal:	1 level for overrange indication
Printout command signal:	Positive pulse output after the completion of measurement
Output logic:	Switchable (PC logic not switchable)
Output signal:	TTL level fan-out = 2, COMS compatible

◎ Open collector output (NPN type)

Measured data:	Transistor ON when negative logic is logic 1
Polarity signal:	Transistor ON for negative indication
Overrange signal:	Transistor ON for overrange indication
Printout command signal:	Transistor ON after the completion of measurement
Output logic:	Switchable (PC logic not switchable)
Transistor output capacity:	Voltage 30 V DC max., Current 10 mA max. Output saturation voltage 1.2 V or less at 10 mA

◎ Enable

Enable input:	Shorting the ENABLE and D.COM terminals or bringing their potential to the "0" level causes BCD output to be high impedance (TTL) or the transistor to be turned OFF.
Control signal "0" level:	0 to 1.5 V with respect to the D.COM terminal
Control signal "1" level:	3.5 to 5 V with respect to the D.COM terminal

● External Control

Hold:	The hold function is activated by shorting the HOLD and D.COM terminals or bringing the potentials of them to the "0" level.
Digital zero:	The digital zero function is activated by shorting the DZ and D.COM terminals or bringing their potential to the "0" level.
Peak hold:	The peak hold function is activated by shorting the PH and D.COM terminals or bringing their potential to the "0" level.
Control signal "0" level:	0 to 1.5 V with respect to the D.COM terminal
Control signal "1" level:	3.5 to 5 V with respect to the D.COM terminal

8. List of the Parameters

8.1 Condition Data

Mene	Parameter	Initial (*)	P.L	Selections/ Ranges	Function/Remarks
P.L (P.L)	Protect level	PL0	PL2	PL0/PL1 PL2/PL3	Selects the protect level for preventing incorrect operation. The higher the protect level, the more limitations are imposed on a set parameter.
P.VH (PVH)	PH select	PH	PL0	PH/VH/PVH	Selects the type (peak hold, valley hold, or peak-valley hold) that is activated when the PH function is enabled.
r.RNG (RANG)	Input range	JPb	PL1	PA/Pb/JPA/JPb	Selects the input range.
AVG (AVG)	Average rate	1	PL1	1/2/4/8/10/20 40/80/100/200	Selects the number of averaging times (sampling). Sampling rate is set as the number of averaging times of 12.5/sec (80 ms). This is the actual sampling time.
MAV (MAV)	Moving average rate	OFF	PL0	OFF/2/4 8/16/32	Selects the number of moving averaging times. (Smaller filtering effect OFF 2 4 8 16 32 Larger filtering effect)
S.WD (S.WD)	Step-wide	1	PL0	1/2/5/0	Sets the resolution of the least significant digit. (When it is set to "5", the least significant digit indicates only "0" or "5".)
b.LNK (BLNK)	Display blank level	OFF	PL0	OFF/b-3/b-2 b-1/on	Selects display brightness. (Bright OFF b-3 b-2 b-1 ON Extinguished)
UNIT (UNIT)	Temperature display unit	C	PL0	C/F	The unit setup of display temperature is performed. Centigrade is displayed by C and fahrenheit is displayed by F.
DLT (DLT)	Digital limiter type	CUT	PL0	CUT/OVER	Sets the displayable range type. When CUT is selected, the set value is displayed; when OVER is selected, "o.L." is displayed.
BCD.L (BCD.L)	BCD output logic	NLO	PL0	NLO/PLLO	Selects the BCD output logic (N: negative logic, P: positive logic). * Only when BCD outputs are provided
D.VP (D.VP)	DZ backup	OFF	PL0	OFF/on	Selects whether to backup the digital zero value when power is disconnected.
LINE (LINE)	Linearization	CLR	PL0	CLR/OFF/on	Selects the enable (ON) /disable (OFF) of the linearize function and data clara (CLR).
TR.T (TR.T)	Tracking zero correction time	00	PL0	00 - 99	Sets the enable/disable of the tracking zero function and correction time (setpoint/conversion rate).
TR.W (TR.W)	Tracking zero correction width	01	PL0	01 - 99	Sets the correction width of the tracking zero function. * Only when TR.T is a value other than 00.
P.ON (PON)	Power-on delay time	OFF	PL0	OFF - 30	Sets the time (setpoint x 1 sec.) taken from when the power is turned on to the instant when measurement is actually started.

* In case of No switch display option, parameters are set specified values, protect level is "PL3".

8.2 Scaling Data

Mene	Parameter	Initial (*)	P.L	Selections/ Ranges	Function/Remarks
d.LHI (DLHI)	Digital limiter HI	9999	PL0	-9999 - 9999	Sets the high limit of the displayable range. (If a value exceeding the digital limiter HI setpoint is input, the display value is not updated, but is held at the set value.)
d.LLO (DLLO)	Digital limiter LO	-9999	PL0	-9999 - 9999	Sets the high limit of the displayable range. (If a value below the digital limiter LO setpoint is input, the display value is not updated, but is held at the set value.)


* In case of No switch display option, parameters are set specified values, protect level is "PL3".

9. Error Messages

Error Display	Description	How to Recover or Remedy
	An input value or display value has exceeded the measurement range.	Use the panelmeter within the specified measurement and display ranges.
	Microcomputer is waiting for data to be input.	Check if the number of averaging times is set to an appropriate value.
	Meter's internal memory failure	Turn power on again. If it does not recover from the failure, contact your sales representative or our sales office directly.
	Condition data error	Carry out condition data setting again. * Modify one or more data and go through the parameters once.
	Scaling data error	Carry out scaling data setting again. * Modify one or more data and go through the parameters once.
	Linearize data error	Carry out linearize data setting again. * Modify one or more data and go through the parameters once.
	Shift data error	Carry out shift data setting again.
	Digital zero value backup data error	Write the digital zero value.

* Turning the power on with all the front-panel keys (Enter, Mode, Shift, and Increment) held down, allows you to reset all the parameters to the defaults.

10. Timing Chart



A value set using the AVG parameter in the condition data becomes the practical sampling rate of the A8000 series.

Set AVG Counts	Set Sampling Rate	Set Sampling Period	Set AVG Counts	Set Sampling Rate	Set Sampling Period
1	12.5times/sec	80ms	20	0.625 times/sec	1.6s
2	6.25 times/sec	160ms	40	0.3125 times/sec	3.2s
4	3.125 times/sec	320mS	80	0.15625 times/sec	6.4s
8	1.5625 times/sec	640ms	100	0.125 times/sec	8s
10	1.25 times/sec	800ms	200	0.0625 times/sec	16s

11 Warranty and After Sales Service

11.1 Warranty

The manufacturer warrants to the original retail customer its 46AC series universal digital panel meter to be free of defects in material and workmanship for use under normal care and will repair or replace any meter at no charge to the customer during the one (1) year warranty period of the meter.

11.2 After Sales Service

Under strict quality control measures, this product was manufactured, tested, inspected and shipped. Should a defect in manufacture or Workmanship be identified, please return the product to our distributor or directly to us. It would be highly appreciated if you could give a detailed account of the fault and enclose it with the product.

watanabe

WATANABE ELECTRIC INDUSTRY CO., LTD.

6-16-19, Jingumae, Shibuya-ku, Tokyo 150-0001, Japan
Phone: (81)3-3400-6141

Homepage <http://en.watanabe-electric.co.jp/>

(UX-34296o)